

Oulim Theater Lineset Schedule

Distance from Setting Line	Lineset	notes	
		APRON 2	
		PLACARD BATTEN	
		APRON 1	
0.10 M	1	SAFETY CURTAIN	
0.35	2	MAIN CURTAIN	
0.78	3	NO.1 DRAW CURTAIN	
0.93	4	NO.0 SET BATTEN	
1.57	5	NO.1 TOP LIGHT BRIDGE	
2.23	6	NO.1 SET BATTEN	
2.79	7	NO.1 UPPER SOUND REFLECTION BOARD	
3.36	8	NO.2 SET BATTEN	
3.59	9	NO.3 SET BATTEN	
3.95	10	NO.2 DRAW CURTAIN	
4.25	11	NO.4 SET BATTEN	
4.49	12	NO.5 SET BATTEN	
5.17	13	NO.2 TOP LIGHT BRIDGE	
5.84	14	NO.6 SET BATTEN	
6.06	15	NO.7 SET BATTEN	
6.34	16	NO.8 SET BATTEN	
6.90	17	NO.2 UPPER SOUND REFLECTION BOARD	
7.18	18	NO.3 DRAW CURTAIN	
7.52	19	NO.9 SET BATTEN	
7.78	20	NO.10 SET BATTEN	
8.17	21	NO.11 SET BATTEN	
8.78	22	NO.3 TOP LIGHT BRIDGE	
9.40	23	NO.12 SET BATTEN	
9.63	24	NO.13 SET BATTEN	
9.85	25	NO.14 SET BATTEN	
10.16	26	REAR SCREEN	
10.46	27	NO.15 SET BATTEN	
10.95	28	NO.3 UPPER SOUND REFLECTION BOARD	
11.46	29	NO.4 DRAW CURTAIN	
11.90	30	NO.1 BORDER LIGHT	
12.26	31	NO.1 SUSPENTION LIGHT	
12.70	32	NO.16 SET BATTEN	
13.07	33	FRONT SOUND REFLECTION BOARD	
13.56	34	NO.17 SET BATTEN	
13.80	35	NO.18 SET BATTEN	
14.17	36	NO.19 SET BATTEN	
14.39	37	NO.5 DRAW CURTAIN	
14.97	38	NO.2 BORDER LIGHT	
15.32	39	NO.2 SUSPENTION LIGHT	
15.80	40	NO.20 SET BATTEN	
15.98	41	NO.21 SET BATTEN	
16.23	42	NO.22 SET BATTEN	
16.47	43	NO.23 SET BATTEN	
16.70	44	NO.24 SET BATTEN	
17.13	45	UPPER HORIZONTAL LIGHT	
17.55	46	NO.25 SET BATTEN	
17.93	47	NO.26 SET BATTEN	
18.23	48	NO.6 DRAW CURTAIN	
18.40	49	HORIZONT CURTAIN(WHITE)	
18.65	50	HORIZONT CURTAIN(BLACK)	